Information

use ONLY:

NOT TO BE

**NAVIGATION** 

**USED FOR** 



# **NORMAL VFR ARRIVAL ROUTES**

# **Expected Arrival Clearances:**

Arriving: (East) From El Toro proceed to Signal Peak Expect: Enter LEFT Traffic, RWY 20L; report UCI.

Arriving: (SE) Dana Point and Laguna Beach

Expect: Proceed to Signal Peak for LEFT Traffic, RWY 20L; Proceed directly

over or remain just east of UCI for a proper midfield pattern entry to RWY 20L.

Arriving: (SW) Huntington Pier

Expect: Cross over the control tower at or above 1300

for left downwind entry RWY 20L.

Arriving: (W/NW) Mile Square Park

Expect: Cross over the control tower at or above 1300

for left downwind entry RWY 20L.

## MISCELLANEOUS APPROACH FREQUENCIES

ILS Localizer/DME: I-SNA 111.75 108.30 LDA Localizer/DME: I-OJW AFSS: RAL 122.45 VOT: 110.00 ASDE-X in Use: Pilots should operate transponders with Mode C on all TWYs/RWYs

### TRAFFIC PATTERN ALTITUDES

#### **RWY 2L - 20R TPA:**

1056 (1000) small aircraft, 1556 (1500) turbine aircraft over 12500 lbs.

**RWY 2R - 20L TPA:** 

856 (800) small single engine aircraft, 1056 (1000) twin engine aircraft.

# **NORMAL VFR DEPARTURE ROUTES**

Departing E/NE:	El Toro Departure – "Heading 080°"
Departing SE:	Newport Departure – " Heading 150° "
Departing SW:	Mesa Departure – " Heading 220° "
Departing NW:	Orange Departure – " Heading 340° "

Squawk Code, Advisory Frequency and Altitude as assigned.

Pilots not requesting radar service beyond the surface area of the Class C airspace may state "local" when requesting their departure route. (Example: "John Wayne Clearance, Cessna N739MB, west-side parking, Mesa Local Departure.") Local radar service will be terminated upon exiting the 5 nm surface area of the Class C airspace. Pilots must then remain clear of all other regulated airspace, including the upper tier of the Class C airspace.

#### **AVOID OVERFLIGHT OF RWY 20R/2L**

# VFR aircraft - to avoid overflight of RWY 20R/2L:

RWY 20L arrival fly final at 15° angle to RWY. RWY 20L departures turn LEFT 15° at departure end of runway. To avoid overflights of RWY 2L, RWY 2R departures turn RIGHT 15° at departure end of runway.



## **LOCATION**

4 nm S of the City of Santa Ana N33° 40.54′ W117° 52.09′ On Los Angeles Sectional, L3-L4 and Terminal Area Charts

# **Distances from other airports:**

7 nm WSW of MCAS El Toro - CLOSED

16 nm ESE of Long Beach

12 nm SE of Fullerton


19 nm SW of Corona


# Distances from NAVAIDS: (• = DME)

<b>VOR</b> only	7 nm	255°	117.2	ELB
VORTAC	11 nm	110°	115.7•	SLI
VORTAC	22 nm	215°	112.2•	PDZ
VORTAC	34 nm	303°	115.3•	OCN

OMMUNICATIONS FREC eld Elevation: 56 feet MSL	QUENCIES	
ATIS (714) 546-2279		126.00
ASOS (714) 424-0590		
Clearance Delivery		
VFR		121.85
IFR		118.00
John Wayne Ground*	[Unless otherwise assigned by Tower]	
ALL AIRCRAFT		120.80
John Wayne Tower*	[Operates; 0615 - 2300 LCL]	
RWY 20R/2L		126.80
RWY 20L/2R	[RWY 20L/2R CLSD when Tower CLSD]	119.90
Common Traffic Advisory Frequency (CTAF)		126.80
SOCAL Approach Frequ	uencies*	
SW/NW		125.35
E/SE		124.10
NE		121.30
All Jets - Approach		121.30
All Jets - Departure		128.10

\*[NOTE: Monitor ATIS prior to contacting Clearance Delivery, Ground, Tower, or Approach Control for frequencies in use.]





Runway Environment

Taxiway Environment

Runway Holding Position Markings

Run-up Areas

In-Pavement Guard Lights

Taxiway Lead-off Lights



Surface painted hold and enhanced centerline markings at RWY/TWY



Runway Hold Position Signs



Elevated Guard Lights at all intersections

Taxiway Hold Short Position

- 1. "READ BACK" ALL RUNWAY HOLD SHORT INSTRUCTIONS.
- 2. BE VIGILANT WHEN OPERATING IN VICINITY OF TWY H. TWY C. RWY20L INTERSECTION.
- 3. WHEN IN DOUBT TELL CONTROLLERS "UNFAMILIAR" AND REQUEST PROGRESSIVE TAXI INSTRUCTIONS.
- 4. BE FAMILIAR KNOW LAYOUT, SIGNAGE AND MARKINGS.
- 5. YOUR ACTIONS CAN MAKE ALL THE DIFFERENCE!